



Cederroth Eye Wash Heating Cabinet REF 790400 Instructions for recycling



1. Unplug the device!

2. Cut off the plug (A) and lift out the metal element from the cabinet.




3. Unscrew to release the circuit board from the metal plate.



4. In Sweden – recycle at local recycle station.

Markets outside Sweden - return the electronic components to Orkla Wound Care AB, shipping labels will be provided by e-mail by contacting firstaid@cederroth.com.



Thank you for recycling!